


ARCTIC SILVER QUIET DRIVE CROSS-TRAINER 93X-0XXX-05 (Hungary-built Cross-trainer for Domestic Sales)





Customer Support Services PARTS MANUAL rev 14 Jun 2010


OPERATION MANUAL – (ENG) OPERATION MANUAL – (F/S/P)	M051-00K62-A181 M051-00K62-A182
OPERATION MANUAL – (G/D/I)	M051-00K62-A183
OPERATION MANUAL – (JAP)	M051-00K62-A184
SERVICE MANUAL	M051-00K62-A149
TOUCH UP PAINT:	
SPRAY CAN	0017-00008-0204
.5 OZ BOTTLE W/APPLICATOR	0017-00008-0205
.33 OZ PEN	0017-00008-0206
HARDWARE BAG	AK62-00152-0001
POWER CABLE WITH BRACKET ASSEMBLY	AK62-00210-0000
CONSISTS OF:	
120" COAX CABLE ASSY.	AK32-00020-0002
120" POWER EXTENSION CABLE ACCESS PANEL BRACKET	AK32-00078-0001 0K62-01179-0001
F-TYPE PANEL CONNECTOR	0017-00021-2846
#8 PLASTIC GROMMET	0017-00042-0754
PLUG IN OPTION 120/60	GK62-00002-0018
PLUG IN OPTION 240/50 UK	GK62-00002-0019
PLUG IN OPTION 240v AUS	GK62-00002-0020
PLUG IN OPTION 230/50 CONT.	GK62-00002-0021
C-SAFE KIT	GK63-00002-0003

	Page
CONSOLE SUPPORT & DEADSHAFT COVERS	4
HANDLEBARS AND BULLHORNS	5
CONSOLE AND RELATED COMPONENTS	6
UPPER FRAME HARDWARE	7
ROCKER ARMS AND PEDAL LEVERS	8
CRANK COVER AND LOWER CAPS	9
LOWER FRAME SHROUDS AND HARDWARE	10
PEDAL LEVER COMPONENTS	11
PCB, BATTERY, REED SWITCH & BRACKET	12
BEARING-INSERT ASSEMBLY	13
CRANK ARM PULLEY ASSEMBLY	14
DRIVE MODULE	15
DRIVE MODULE HARDWARE	16
CABLES	17

Note: The 93X has both Life Pulse sensors and Telemetry for reading Heart Rate and is pre-wired for attachable LCD TV's.








CONSOLE	OVERLAY/BEZEL/SWITCH	LANGUAGE
AK62-00365-0001	AK62-00190-0001	Eng/Eng
AK62-00365-0002	AK62-00190-0001	Eng+Met
AK62-00365-0003	AK62-00190-0003	Ger/Met
AK62-00365-0004	AK62-00190-0004	Spn/Met
AK62-00365-0006	AK62-00190-0006	Jap/Met
AK62-00365-0007	AK62-00190-0007	Frn/Met
AK62-00365-0008	AK62-00190-0008	Ital/Met
AK62-00365-0009	AK62-00190-0009	Dut/Met
AK62-00365-0010	AK62-00190-0010	Port/Met
AK62-00365-0014	AK62-00190-0001	Turk/Met


Items Not Shown	
Accessory Tray	0K62-01022-0000
Accessory Tray Mounting Screws (2)	0017-00101-1846





Rocker Arms Kit GK62-00002-0070 contents:


Rocker Arms (2) Hardened Spacers (2) Oilite Washers (2) Retaining Rings (2) Loctite 620 Alcohol pad


Rocker Arms AK62-00002-0070 Shaft Collar w/Screws 0K61-01259-0000











This assembly is used 4 times on the drive module assembly.

Service Kit-MGK62-00002-0044 Includes:

- 1 crankshaft
- 2 bearings
- 2 sets of bearing flanges
- 4 weldnuts and flat washers
- 4 bolts

Service Kit- GK62-00002-0045 Includes:

- 1 intermediate shaft
- 2 bearings
- 2 sets of bearing flanges
- 4 nuts and washers
- 4 bolts

